


SPARE FUSES


F1 HEADLIGHTS **10 AMP**

F4 FLASHERS **10 AMP**

F7 CAB PRESSURIZER **20 AMP**

F10 12V **10 AMP**

F13 228 12V **5 AMP**

F16 CONTROLLER POWER **30 AMP**

F2 SLING LUBE **20 AMP**

F5 AXIOM **5 AMP**

F8 PAD LUBE **20 AMP**

F11 RADIO **10 AMP**

F14 DI4 12V **5 AMP**

F3 LEFT REAR MOTOR **5 AMP**

F6 TRACTION **5 AMP**

F9 A/C **30 AMP**

F12 SPARE **5 AMP**

F15 BODAS ELECTRONIC **10 AMP**

R1 HEADLIGHTS

R4 SLING LUBE

R7 LEFT REAR MOTOR

R2 FLASHERS

R5 PAD LUBE

R8 AXIOM

R3 CAB PRESSURIZER

R6 TRACTION